




Instruction Manual

SMP-BC Sanitary Mixproof Valve



ESE02255-EN7

2016-06

Original manual

The information herein is correct at the time of issue but may be subject to change without prior notice

| | |
|--|-----------|
| 1. EC Declaration of Conformity | 4 |
| 2. Safety | 5 |
| 2.1. Important information | 5 |
| 2.2. Warning signs | 5 |
| 2.3. Safety precautions | 6 |
| 3. Installation | 7 |
| 3.1. Unpacking/delivery | 7 |
| 3.2. Recycling | 8 |
| 3.3. Recommended auxiliary equipment (DN125/150) | 9 |
| 3.4. General installation | 10 |
| 3.5. Welding | 11 |
| 4. Operation | 14 |
| 4.1. Operation | 14 |
| 4.2. Fault finding | 14 |
| 4.3. Recommended cleaning | 15 |
| 4.4. Cleaning equipment (optional extra) | 18 |
| 5. Maintenance | 20 |
| 5.1. General maintenance | 20 |
| 5.2. Dismantling of valve | 22 |
| 5.3. Assembly of valve | 24 |
| 5.4. Dismantling of actuator | 25 |
| 5.5. Assembly of actuator | 27 |
| 5.6. Replacement of plug seals | 29 |
| 6. Technical data | 33 |
| 6.1. Technical data | 33 |
| 7. Parts list and service kits | 34 |
| 7.1. Drawings | 34 |
| 7.2. SMP-BC stop valve | 36 |
| 7.3. SMP-BC change-over valve | 38 |
| 7.4. SMP-BC stop valve - size DN125/DN150 | 42 |
| 7.5. Tools for plug seals | 44 |

1 EC Declaration of Conformity

Revision of Declaration of Conformity 2009-12-29

The Designated Company

Alfa Laval Kolding A/S

Company Name

Albuen 31, DK-6000 Kolding, Denmark

Address

+45 79 32 22 00

Phone No.

hereby declare that

Sanitary Mixproof Valve

Designation

SMP-BC PN10

Type

is in conformity with the following directive with amendments:

- Machinery Directive 2006/42/EC
- Regulation (EC) No 1935/2004
- The valve is in compliance with the Pressure Equipment Directive 2014/68/EU and was subjected to the following assessment procedure Module A. Diameters \geq DN125 may not be used for fluids group 1.

The person authorised to compile the technical file is the signer of this document

QHSE Manager, Quality, Health and safety & Environment

Title

Annie Dahl

Name

Kolding

Place

2013-12-03

Date

Signature



Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs.

All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury and/or damage to the valve are avoided.

2.1 Important information

Important information

Always read the manual before using the valve!

WARNING

Indicates that special procedures must be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures must be followed to avoid damage to the valve.

NOTE

Indicates important information to simplify or clarify procedures.

2.2 Warning signs

General warning:



Caustic agents:



Cutting danger:



2 Safety

Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs.

All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury and/or damage to the valve are avoided.

2.3 Safety precautions

Installation:

Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air

Never stick your fingers through the valve ports if the actuator is supplied with compressed air



Operation:

Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Never touch the clip assembly or the actuator piston rod when the actuator is supplied with compressed air

Never touch the valve or the pipelines when processing hot liquids or when sterilizing

Always keep the cleaning pressure lower than the product pressure

Never throttle the outlet of the detecting valve



Always handle lye and acid with great care

Maintenance:

Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Always remove the CIP connections before service

Never service the valve when it is hot

Never service the valve with valve and pipelines under pressure

Never stick your fingers through the valve ports if the actuator is supplied with compressed air



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air

Transportation:

Always ensure that compressed air are released

Always ensure that all connections is disconnected before attempting to remove the valve from the installation

Always drain liquid out of valves before transportation

Always use predesigned lifting points if defined

Always ensure sufficient fixing of the valve during transportation - if specially designed packaging material is available, it must be used

The instruction manual is part of the delivery.

Study the instructions carefully.

Stop valve: With one valve body. Change-over valve: With three valve bodies.

CIP = Cleaning In Place

3.1 Unpacking/delivery

Step 1

CAUTION!

Alfa Laval cannot be held responsible for incorrect unpacking.

Check the delivery for:


1. Complete valve, standard or three-bodied valve
2. Delivery note
3. Instruction manual

Step 2

Remove possible packing materials from the valve ports. Avoid damaging the air connection, the valve ports, the detecting valve and the CIP valve.

Caution!


Remove
packing
materials!



Step 3

Inspect the valve for visible transport damage.

Inspection!



3 Installation

3.2 Recycling

- **Unpacking**

- Packing material consists of wood, plastics, cardboard boxes and in some cases metal straps
- Wood and cardboard boxes can be re-used, recycled or used for energy recovery
- Plastics should be recycled or burnt at a licensed waste incineration plant
- Metal straps should be sent for material recycling.

- **Maintenance**

- During maintenance, oil and wearing parts in the machine are replaced
- All metal parts should be sent for material recycling
- Worn out or defective electronic parts should be sent to a licensed handler for material recycling
- Oil and all non-metal wear parts must be disposed off in agreement with local regulations

- **Scrapping**

- At end of use, the equipment must be recycled according to the relevant, local regulations. Besides the equipment itself, any hazardous residues from the process liquid must be considered and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact your local Alfa Laval sales company
-

The valve sizes DN125-150 are very heavy.

Therefore Alfa Laval recommends manufacturing and usage of auxiliary equipment. A proposal is given below.

Please note that the auxiliary equipment **cannot** be supplied by Alfa Laval.

The items refers to the drawings, parts list and service kits, see chapter 7 Parts list and service kits

3.3 Recommended auxiliary equipment (DN125/150)

Step 1


For lifting the valve:

Screw an eye bolt (6 mm/0.25 inch) into top pin (10). Using a small hook crane or similar, lift the valve by an eye bolt.

Trestle:

- The purpose of the trestle is to support the valve during dismantling and assembly.
- The trestle is made of a base plate, two support plates, two rubber linings and four bolts.
- The rubber linings are attached to the support plates so that the valve/actuator will rest on these.
- To prevent the valve from turning during dismantling and reassembly the trestle must be made with the correct measurements (see drawings below - all measurements are in mm.)


Trestle




Side view



Top view




End view



Step 2

1. Place the valve in the trestle.
2. Make sure that the actuator rests on the rubber linings on the trestle support plates.
3. Dismantle/assemble the valve



3 Installation

Study the instructions carefully and pay special attention to the warnings!

The valve has welding ends as standard but can also be supplied with fittings.

CIP = Cleaning In Place

3.4 General installation

Step 1



- Always read the technical data thoroughly (see 6 Technical data).
- Always release compressed air after use.
- Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air.

CAUTION!

Alfa Laval cannot be held responsible for incorrect installation.


Step 2

Install the valve so that:


- The actuator is turned to the uppermost point.
- The detecting valve is self-draining.
- The flow is against the closing direction to avoid water hammer.

A = Inlet

Stop valve



Change-over valve



Avoid water hammer!


Step 3

Avoid stressing the valve.

Pay special attention to:

- Vibrations.
- Thermal expansion of the tubes.
- Excessive welding.
- Overloading of the pipelines.


Risk of damage!



Step 4

Fittings:


Ensure that the connections are tight.



Study the instructions carefully and pay special attention to the warnings.
The valve has welding ends as standard.
Weld carefully.
Check the valve for smooth operation after welding.

Step 5

Air connection:



Step 6


CIP connection:

1. See description of cleaning and optional extras see sections 4.3 Recommended cleaning and 4.4 Cleaning equipment (optional extra)
2. Connect CIP correctly.

A = CIP in

B = R3/8" (BSP), external thread

C = CIP out/ leakage drain




3.5 Welding

Step 1



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



3 Installation


Study the instructions carefully and pay special attention to the warnings.
The valve has welding ends as standard.
Weld carefully.
Check the valve for smooth operation after welding.

Step 2

Dismantle the valve in accordance with steps 1-3, section 5.2

Dismantling of valve

Pay special attention to the warnings!




Step 3

NOTE!

Always weld the valve body into the pipelines so that the valve body seal rings can be replaced (change-over valve).
Maintain the minimum clearances (A and B) so that the lower valve plug (change-over valve) and the actuator with the internal parts can be removed.


| Valve size | A | B ₁ | B ₂ (Incl. top unit) |
|---------------|------------------------------|----------------|------------------------------------|
| | mm (figures in () = inches) | | |
| DN40/38mm | 280 (11) | 550 (22) | 730 (29) |
| DN50/51 mm | 305 (12) | 550 (22) | 730 (29) |
| DN65/63.5mm | 360 (14) | 550 (22) | 730 (29) |
| DN80/76mm | 410 (16) | 600 (24) | 780 (31) |
| DN100/101.6mm | 470 (19) | 650 (26) | 830 (33) |
| DN125 | - (-) | 750 (30) | 930 (37) |
| DN150 | - (-) | 790 (31) | 970 (38) |

Stop valve



1 = CAUTION!

Change-over valve (upper valve body)




Step 4

Assemble the valve in accordance with steps 4-6, section 5.3

Assembly of valve

Pay special attention to the warnings!




Study the instructions carefully and pay special attention to the warnings.
The valve has welding ends as standard.
Weld carefully.
Check the valve for smooth operation after welding.

Step 5

Pre-use check:

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



4 Operation

The valve is adjusted and tested before delivery.

Study the instructions carefully and pay special attention to the warnings! Pay attention to possible faults.

CIP = Cleaning In Place

The items refer to the drawing and parts list, see section 7 Parts list and service kits.

4.1 Operation

Step 1



Always read the technical data thoroughly (see chapter 6 Technical data).

Always release compressed air after use.



Never touch the clip assembly or the actuator piston rod when the actuator is supplied with compressed air.


CAUTION!

Alfa Laval cannot be held responsible for incorrect operation.

Step 2



Never touch the valve or the pipelines when processing hot liquids or when sterilizing.



4.2 Fault finding

NOTE! Study the maintenance instructions carefully before replacing worn parts - see section 5.1 General maintenance

| Problem | Cause/result | Possible solution |
|---|--|---|
| Product leakage through the detecting valve (closed valve) | <ul style="list-style-type: none">- Worn seal rings- The two seal rings affected by different products- Incorrect fitting of seal rings- Product deposits on the seat and/or plug | <ul style="list-style-type: none">- Replace the seal rings- Select a different rubber grade- Frequent cleaning |
| Product leakage through the detecting valve (open valve) | <ul style="list-style-type: none">- Worn O-ring (26a)- Worn spindle (26d)- Product deposits on the seat and/or plug | <ul style="list-style-type: none">- Replace the O-ring- Replace the spindle- Frequent cleaning |
| Product leakage at stem and/or clamp | <ul style="list-style-type: none">- Worn/product affected lip seal (22a) and/or seal rings (22c, 27) | <ul style="list-style-type: none">- Replace the seal rings- Select a different rubber grade |
| Product leakage through middle or lower valve body (closed lower plug) | <ul style="list-style-type: none">- Worn/product affected plug seal ring- Loose parts (vibrations)- Product deposits on the seat and/or plug | <ul style="list-style-type: none">- Replace the seal ring- Select a different rubber grade- Tighten the loose parts- Frequent cleaning |
| <ul style="list-style-type: none">- Air leakage through the CIP and detecting valve- Air leakage at the actuator | Worn seal rings | Replace the seal rings |

The valve is designed for cleaning in place (CIP)
 Study the instructions carefully and pay special attention to the warnings!
 NaOH = Caustic soda
 HNO₃ = Nitric acid

4.3 Recommended cleaning

Step 1



Always handle lye and acid with great care.

Caustic danger!



Always use
rubber gloves!




Always use
protective goggles!

Step 2



Never touch the valve or the pipelines when sterilizing.



Burning danger!



Step 3




Always keep the cleaning pressure lower than the product pressure.

Never throttle the outlet of the detecting valve (risk of mixing because of overpressure).

- 1 = CIP in
- 2 = CIP valve
- 3 = Detecting valve
- 4 = CIP out

Leakage chamber: 60-100 kPa



4 Operation

The valve is designed for cleaning in place (CIP)

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic soda

HNO₃ = Nitric acid

Step 4

Examples of cleaning agents:

Use clean water, free from chlorides.

1. 1% by weight NaOH at 70° C (158° F)

| | | | | |
|---------------------------|---|------------------------------|---|-----------------|
| 1 kg (2.2 lbs) NaOH | + | 100 l (26.4 gal) water | = | Cleaning agent. |
|---------------------------|---|------------------------------|---|-----------------|

2. 0.5% by weight HNO₃ at 70° C (158° F)

| | | | | |
|--|---|------------------------------|---|-----------------|
| 0.7 l (0.2 gal) 53% HNO ₃ | + | 100 l (26.4 gal) water | = | Cleaning agent. |
|--|---|------------------------------|---|-----------------|

| | | | | |
|--------------------------------|---|------------------------------|---|-----------------|
| 2.2 l (0.6 gal) 33% NaOH | + | 100 l (26.4 gal) water | = | Cleaning agent. |
|--------------------------------|---|------------------------------|---|-----------------|

Step 5

Recommended cleaning periods:

Cleaning periods of 10-15 seconds for the leakage chamber.

| Product | Periods |
|-----------|---------|
| Milk | 1-2 |
| Yoghurt | 3-5 |
| Beer | 2-5 |
| Cold wort | 5-10 |

Recommended cleaning flow rates:

(For special processes, see Step 6).

Leakage chamber: 12-15 l/min (3.2 - 4.0 gpm).

Step 6

1. Avoid excessive concentration of the cleaning agent

⇒ **Dose gradually!**

2. Adjust the cleaning flow to the process

Milk sterilization/viscous liquids

⇒ **Increase the cleaning flow!**

Step 7

Internal leakage in the valve is externally visible by means of the outlet of the detecting valve.

Always rinse well with clean water after the cleaning.

NOTE!

The cleaning agents must be stored/disposed of in accordance with current rules/directives.

Always rinse!



Clean water Cleaning agents

Step 8

Cleaning cycle:

Pay special attention to the warnings!


Closed stop valve:

Cleaning of the leakage chamber

A = Product

B = CIP in

C = CIP out



The valve is designed for cleaning in place (CIP)

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic soda


HNO₃ = Nitric acid

Step 9

Open stop valve:

Cleaning of the valve body and the leakage chamber

A = CIP




Step 10

Closed change-over valve:

Cleaning of the upper valve body

A = CIP

B = Product



4 Operation

The installation kits are for cleaning of the leakage chamber when the valve is closed.

The combination of the different kits depends on the actual applications.

CIP = Cleaning In Place

4.4 Cleaning equipment (optional extra)

Step 1

Installation kit A for CIP and leakage connections of a single valve (PVDF/stainless steel tubes)


Contents:

Pos. 1 - Welding male part

Pos. 2 - Fitting PVDF female

Pos. 3 - Tube PVDF

Pos. 4 - Leakage tube AISI 316



Step 2


Installation kit B (inlet) for parallel connection of CIP (PVDF tubes)

Contents:

Pos. 2 - Fitting PVDF female

Pos. 3 - Tube PVDF

Pos. 5 - Fitting PVDF



The installation kits are for cleaning of the leakage chamber when the valve is closed.
The combination of the different kits depends on the actual applications.
CIP = Cleaning In Place

Step 3


Installation kit C for CIP and leakage connection of a single valve (stainless steel tubes)

Contents:

Pos. 1 - Welding part

Pos. 4 - CIP leakage tube AISI 316

* Adjust and weld during installation.




Step 4

Installation kit D for leakage connection (stainless steel tubes)

Contents:

Pos. 4 - Leakage tube AISI 316



5 Maintenance

Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

CIP = Cleaning In Place.

Always keep spare rubber seals, lip seals and guide rings in stock.

5.1 General maintenance

Step 1



- **Always** read the technical data thoroughly (see 6 Technical data).
- **Always** release compressed air after use.
- **Always** remove the CIP connections before service.


CAUTION!

All scrap must be stored/disposed of in accordance with current rules/directives.

Step 2




- **Never** service the valve when it is hot.
- **Never** service the valve with valve and pipelines under pressure.



Step 3




Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



Step 4



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air.



Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

CIP = Cleaning In Place.

Always keep spare rubber seals, lip seals and guide rings in stock.

The valve is designed so that single internal leakages do not result in the products becoming mixed.

Internal leakage in the valve is externally visible.

Check the valve for smooth operation after service.

| | Valve rubber seals | Valve lip seal | Valve guide rings (for DN125 and DN150 only) | Actuator rubber seals | Bonnet guide ring |
|---|--|--|--|---|---|
| Preventive maintenance | Replace after 12 month | Replace when replacing the valve rubber seals | Replace when required | Replace after 5 years | Replace when replacing the actuator rubber seals (*) |
| Maintenance after leakage (leakage normally starts slowly) | Replace by the end of the day | Replace when replacing the valve rubber seals | Replace when required | Replace when possible | |
| Planned maintenance | <ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for planning of inspections Replace after leakage | Replace when replacing the valve rubber seals | Replace when required | <ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the actuator - Use the statistics for planning of inspections Replace after air leakage | Replace when replacing the actuator rubber seals (*) |
| Lubrication (USDAH1 approved oil/grease) | Before fitting: Silicone oil or silicone grease | Before fitting: Silicone oil or silicone grease | None | Before fitting: Silicone oil or silicone grease | None |

(*) = IMPORTANT

Check that the guide ring is fitted if replacing the bonnet (except on DN125 and DN150).

Recommend spare parts

Service kits see chapter 7 Parts list and service kits .

Order service kits from the service kits list see chapter 7 Parts list and service kits .

Ordering spare parts

Contact the sales department.

5 Maintenance

Stude the instructions carefully.

The items refer to the parts list and service kits section - see chapter 7 Parts list and service kits .

Handle scrap correctly.


Removal of plug seals, please see the special instructions, section 5.6 Replacement of plug seals.

Pre-use check


1. Ensure that the valve plug seals against the seat.
- Pay special attention to the warnings!**
2. Pressurise the leakage chamber by means of water.
3. Check that the plug seals are tight (no water leakage through the valve ports).
4. Supply compressed air to the actuator.
5. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!

Top view
Water 3-4 bar



1 = In
2 = CIP valve
3 = Detecting valve
4 = Out




Inspection!

5.2 Dismantling of valve

Step 1

Change-over valve:


1. Loosen and remove lower clamp (24).
2. Remove lower valve body (32).
3. Pull out lower seal ring (27).



Step 2

Change-over valve:

1. Remove lower plug (31b).
2. Pull off lower o-ring (29) from the plug.
3. Loosen and remove middle clamp (24).
4. Remove middle valve body (24).
5. Pull out upper seal ring (27).



Use a piece of 5-6 mm
(0.2 inch) flat bar!

Counterhold with a
spanner

Stude the instructions carefully.

The items refer to the parts list and service kits section - see chapter 7 Parts list and service kits .


Handle scrap correctly.

Removal of plug seals, please see the special instructions, section 5.6 Replacement of plug seals.

Step 3


1. Supply compressed air to the actuator.
2. Loosen and remove upper clamp (24).
3. Lift out the actuator together with plug (23).
4. Release compressed air.

Pay special attention to the warnings!




Step 4

1. Remove clip assembly (12), (not for DN125/DN150: see illustration)
2. Pull out plug (23).
3. Remover stem seal (22), (not DN125/DN150: see illustration)



DN125/DN150

Counterhold!




Turn plug anticlockwise with a spanner

Step 5

Change-over valve:

1. Remove stem (30) from plug (23a).
2. Pull off upper o-ring (29) from the plug.




Use a spanner!

Use a spanner!

Step 6

1. Remove air fittings (26g, 26h).
2. Unscrew plugs (26f).
3. Remove the internal parts.



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.


Lubricate the rubber seals and the lip seal before fitting them.

Fitting of plug seals, please see the special instructions, see section 5.6 Replacement of plug seals

5.3 Assembly of valve

Step 1


1. Fitting internal parts.
2. Screw in plugs (26f).
3. Fit air fittings (26g, 26h).



Step 2


Change-over valve

1. Slide upper o-ring (29) onto plug (23a).
2. Fit stem (30) in the plug - use Loctite or similar on thread.




Step 3

1. Push stem seal (22) onto plug (23), (not DN125/DN150: see illustration).
2. Fit the plug in piston (11).
3. Fit clip assembly (12), (not DN125/DN150: see illustration).



Turn plug clockwise with a spanner




DN125/DN150

Step 4

1. Supply compressed air to the actuator.
2. Lift in the actuator together with plug (23).
3. Fit and tighten upper clamp (24).
4. Release compressed air.

Pay special attention to the warnings!




*Study the instructions carefully.
The imtes refer to the parts list and service kits section.
Handle scrap correctly.*

Step 5

Change-over valve:

1. Fit upper ring (27) in middle valve body (28).
2. Position the middle valve body on upper valve body (25).
3. Fit and tighten middle clamp (24).
4. Slide lower o-ring (29) onto lower plug (31b).
5. Fit the lower plug - use Loctite or similar.




Use a piece of 5-6 mm
(0.2 inch) flat bar!

Counterhold with a
spanner!

Step 6

Change-over valve:

1. Fit lower seal ring (27) in lower valve body (32).
2. Position the lower valve body on middle valve body (28).
3. Fit and tighten lower clamp (24).




5.4 Dismantling of actuator

Step 1

1. Rotate cylinder (5) to unlock lock wire (7).
2. Remove the lock wire.

Rotate by hand or with the service tool!



5 Maintenance


Study the instructions carefully.

The imtes refer to the parts list and service kits section.

Handle scrap correctly.


Step 2

1. Disconnect cylinder (5) from bonnet (16).
2. Pull off o-ring (13) from the bonnet.




Step 3

1. Pull out piston (11) and spring packet (6).
2. Pull off o-rings (2, 9) from the piston.
3. Remove guide ring (8) from the piston (DN125/DN150).




Step 4

- Remove guide ring (17) from bonnet (16).
- Remove guide rings (18, 19) from bonnet (16) (DN125/DN150)




DN125/DN150



Step 5

Remove lip seal (20) from bonnet (16), (DN125/DN150).




*Study the instructions carefully.
The items refer to the parts list and service kits section.
Lubricate the rubber seals before fitting them.*

5.5 Assembly of actuator

Step 1


Fit lip seal (20) in bonnet (16) (DN125/DN150).



Step 2


Fit guide ring (17) in bonnet (16).

Fit guide rings (18, 19) in bonnet (16) (DN125/DN150).




Step 3

1. Fit guide ring (8) on piston (11) (DN125/DN150).
2. Fit o-rings (2, 9) on the piston.
3. Push the piston and spring packet (6) into cylinder (5).



Step 4

1. Slide o-ring (13) onto bonnet (16).
2. Fit cylinder (5) on the bonnet.



5 Maintenance


Study the instructions carefully.

The items refer to the parts list and service kits section.

Lubricate the rubber seals before fitting them.

Step 5


1. Rehook lock wire (7) through the slot in cylinder (5) in the hole in bonnet (16).
2. Rotate the cylinder 360° (see illustration).



Rotate by hand or with the service tool!

NOTE!

Rotate cylinder (5) further 180° in relation to bonnet (16) so that the top and bottom air connections are fixed on the same side.



Bottom air connection

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.


Do **not** lubricate the rubber seals or the tool parts before fitting the seals.

5.6 Replacement of plug seals

Step 1

Removing the seal rings

Remove the old seal rings by cutting them through and pulling them out of the grooves.



IMPORTANT! Before reading step 2-4, please see section 7.5 Tools for plug seals

5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Do **not** lubricate the rubber seals or the tool parts before fitting the seals.

Step 2


Fitting the seal rings (For stop and change-over valves).

Lower (small) seal ring.

1. Carefully grease the seal with Klüber Paraliq GTE 703 (USDA H1) - do NOT grease on back of seal!
2. Fit the small seal on the inner guide ring (6). Remember to mount the flat side of seal upwards as shown on figure.
3. Fit support part (7) for smaller seal.
4. Lubricate the ends (A) of the support part (7) and the outer guide ring (5) with Klüber Paraliq GTE 703 (USDA H1) and assemble the tool.
5. In a hydraulic press, the outer guide ring (5) is pressed downwards so that the seal is fitted in the groove of the valve plug.
IMPORTANT! The outer guide ring (5) must be closed quickly until metal contact with the support part (7). Normally, the inner guide ring (6) is moved upwards during closing; otherwise lift the pin (2) while fixture is still closed.
6. If the seal is not fitted correctly in the groove this can be fixed with a screwdriver.
7. Always remember to release air behind the seal after fitting.

Upper valve plug:

(Stop valve and change-over valve)



B = Grease


C = No grease

D = **NOTE!** Flat side up!

A = Lubricate ends

* = Only for 38-51 mm/DN40-50 upper change-over plug.

DN125/150 only



Spacer (13) is only used when A is between 5.5-5.9 mm

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Do **not** lubricate the rubber seals or the tool parts before fitting the seals.

Step 3


Fitting the seal rings (for stop and change-over valves)

Upper (large) seal ring

1. Carefully grease the seal with Klüber Paraliq GTE 703 (USDA H1) - Do NOT grease on back of seal!
2. Fit the large seal on the inner guide ring (3). Remember to mount the flat side of seal upwards as shown on figure.
3. Lubricate the ends (A) of the support part (4) and the outer guide ring (1) with Klüber Paraliq GTE 703 (USDA H1) and assemble the tool.
4. In a hydraulic press, the outer guide ring (1) is pressed downwards so that the seal is fitted in the groove of the valve plug.
IMPORTANT! The outer guide ring (1) must be closed quickly until metal contact with the support part (4). Normally, the inner guide ring (3) is moved upwards during closing; otherwise lift the pin (2) while fixture is still closed.
5. If the seal is not fitted correctly in the groove this can be fixed with a screwdriver.
6. Always remember to release air behind the seal after fitting.

Upper valve plug:

(Stop valve and change-over valve)



B = Grease


C = No grease

D = **NOTE!** Flat side up!

A = Lubricate ends

* = Only for 38-51 mm/DN40-50 upper change-over plug.

DN125/150 only



Spacer (13) is only used when A is between 5.5-5.9 mm

5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Do **not** lubricate the rubber seals or the tool parts before fitting the seals.


Step 4

Fitting the seal rings (for change-over valves)

1. Carefully grease the seal with Klüber Paraliq GTE 703 (USDA H1).
2. Fit the seal on the inner guide ring (9). Remember to mount the flat side of seal upwards as shown on figure.
3. Fit support part (10)
4. Lubricate the ends of the support part (10) and the outer guide ring (8) with Klüber Paraliq GTE 703 (USDA H1) and assemble the tool.
5. In a hydraulic press, the outer guide ring (8) is pressed downwards so that the seal is fitted in the groove of the valve plug.
IMPORTANT! The outer guide ring (8) must be closed quickly until metal contact with the support part (10). Normally, the inner guide ring (9) is moved upwards during closing; otherwise lift the pin (2) while fixture is still closed.
6. If the seal is not fitted correctly in the groove this can be fixed with a screwdriver.
7. Always remember to release air behind the seal after fitting.

Lower valve plug:


(Change-over valve)




B = Grease

C = No grease

D = **NOTE!** Flat side up!



A = Lubricate ends



*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

6.1 Technical data

SMP-BC is remote-controlled by means of compressed air. The valve is a normally closed (NC) valve.

The valve is fitted with two small pneumatic normally open (NO) valves, a detecting valve and a CIP-valve. The valve plug (the upper plug in a change-over valve) has two seals, forming a leakage chamber under atmospheric pressure between them.

| Data | |
|---|---|
| Max. product pressure | 1000 kPa (10 bar/145 psi) |
| Min. product pressure | Full vacuum |
| Temperature range | -10°C to 140°C (EPDM) (14°F to 284°F) |
| Air pressure, actuator | 500 to 800 kPa (5-8 bar) (72.5 to 116 psi) |
| Air consumption (litres free air) | |
| - 38mm, 51mm, DN40, DN50 | 0.2 x air pressure in bar |
| - 63.5mm, 76mm, 101.6mm, DN65, DN 80, DN100 | 0.7 x air pressure in bar |
| DN125/DN150, NC | |
| - for opening the valve | 1.5 x air pressure in bar |
| - support air for closing the valve | 3.6 x air pressure in bar |
| DN125/DN150, NO | |
| - for opening the valve | 2.2 x air pressure in bar |
| - support air for closing the valve | 2.9 x air pressure in bar |
| Materials | |
| Product wetted steel parts | AISI 316L |
| Finish | Semi bright |
| Other steel parts | AISI 304 |
| Product wetted seals | EPDM (standard) |
| Other seals | Nitrile (NBR) |
| Alternative product wetted seals | Nitrile (NBR) and Fluorinated rubber (FPM) |

Noise

One meter away from - and 1.6 meter above the exhaust the noise level of a valve actuator will be approximately 77db(A) without noise damper and approximately 72 db(A) with damper - measured at 7 bars air-pressure.


Weight (kg)

| Size | 38 mm | 51 mm | 63.5 mm | 76.1 mm | 101.6 mm | 40 DN | 50 DN | 65 DN | 80 DN | 100 DN | 125 DN | 150 DN |
|---------------------------------|-------|-------|---------|---------|----------|-------|-------|-------|-------|--------|--------|--------|
| Weight (kg) - Stop valve | 6.0 | 6.3 | 12.8 | 13.3 | 16.6 | 6.0 | 6.3 | 12.8 | 14.0 | 16.6 | 43.4 | 44.5 |
| Weight (kg) - Change-over valve | 7.7 | 8.1 | 15.0 | 17.0 | 23.0 | 7.7 | 8.1 | 15.0 | 18.0 | 23.0 | | |

7 Parts list and service kits


The items refer to the parts lists in the following sections.

7.1 Drawings




CIP/detecting valve (period 9304-9504)

The drawing show SMP-BC stop valve, change-over valve



CIP/detecting valve (period 9505-)

The drawing show SMP-BC stop valve, change-over valve and stop valve sixes DN125/DN150




Stem seal

The drawing show SMP-BC stop valve, change-over valve


7 Parts list and service kits

The items refer to the parts lists in the following sections.

Stop valve




Change-over valve



7 Parts list and service kits

The items refer to the parts lists in the following sections.

7.2 SMP-BC stop valve



* = CIP/detecting valve.
Diam. ø32.
(Period 9505-)

** = CIP/detecting valve.
Diam. ø27.
(Period 9304-9504)

7 Parts list and service kits

The items refer to the parts lists in the following sections.

Parts list

| Pos. | Qty | Denomination |
|--------|-----|--------------------------|
| 1 | 1 | Cap |
| 2 □ | 2 | O-ring |
| 4 | 1 | Plug |
| 5 | 1 | Cylinder |
| 6 | 1 | Spring packet |
| 7 □ | 1 | Lock wire |
| 9 □ | 1 | O-ring |
| 11 | 1 | Piston |
| 12 □ | 1 | Clip, complete |
| 13 □ | 1 | O-ring |
| 15 | 1 | Air fitting, swivel tee |
| 16 | 1 | Bonnet |
| 17 □ | 1 | Guide ring |
| 22 | 1 | Lip seal kit |
| 22a ♦○ | 1 | Lip seal |
| 22b | 1 | Plate |
| 22c ♦○ | 1 | Seal ring |
| 23 | 1 | Plug |
| 23a | 1 | Plug |
| 23b ♦○ | 1 | Seal ring |
| 23c | 1 | Seal ring |
| 24 | 1 | Clamp complete |
| 25 | 1 | Valve body |
| 26 ★ | 1 | Internal parts |
| 26a ♦★ | 2 | O-ring, NBR |
| 26b ★ | 2 | Spring |
| 26c ♦★ | 2 | O-ring |
| 26d ★ | 2 | Spindle |
| 26e ♦★ | 2 | O-ring, HNBR |
| 26f ★ | 2 | Plug |
| 26g ★ | 1 | Air fitting, swivel tee |
| 26h | 1 | Air fitting, swivel bend |

Service kits

| Denomination | DN 40 38 mm | DN 50 51 mm | DN65 63.5 mm | DN 80 76 mm | DN 100 101.6 mm |
|---|----------------|----------------|-----------------|----------------|--------------------|
| Service Kits for Actuator, detecting/CIP-valve ø32 | | | | | |
| □ Service Kit | 9611920149 | 9611920149 | 9611920150 | 9611920151 | 9611920151 |
| Product wetted parts | | | | | |
| For detecting / CIP-valve ø32 | | | | | |
| ♦ Service kit EPDM | 9611920272 | 9611920272 | 9611920273 | 9611920274 | 9611920275 |
| ♦ Service kit NBR | 9611920276 | 9611920276 | 9611920277 | 9611920278 | 9611920279 |
| ♦ Service kit FPM | 9611920280 | 9611920280 | 9611920281 | 9611920282 | 9611920283 |
| Product wetted parts | | | | | |
| Service kit for valve with ø27 detecting/CIP-valve | | | | | |
| ○ Service kit EPDM | 9611920164 | 9611920164 | 9611920165 | 9611920166 | 9611920167 |
| ○ Service kit NBR | 9611920168 | 9611920168 | 9611920169 | 9611920170 | 9611920171 |
| ○ Service kit FPM | 9611920172 | 9611920172 | 9611920173 | 9611920174 | 9611920175 |

Parts marked with □♦○★△ are included in the service kits.


Recommended spare parts: Service kits.

900-102/3

7 Parts list and service kits

The items refer to the parts lists in the following sections.

7.3 SMP-BC change-over valve



7 Parts list and service kits

The items refer to the parts lists in the following sections.

Parts list

| Pos. | Qty | Denomination |
|--------|-----|--------------------------|
| 1 | 1 | Cap |
| 2 □ | 2 | O-ring |
| 4 | 1 | Plug |
| 5 | 1 | Cylinder |
| 6 | 1 | Spring packet |
| 7 □ | 1 | Lock wire |
| 9 □ | 1 | O-ring |
| 11 | 1 | Piston |
| 12 □ | 1 | Clip, complete |
| 13 □ | 1 | O-ring |
| 15 | 1 | Air fitting, swivel tee |
| 16 | 1 | Bonnet |
| 17 □ | 1 | Guide ring |
| 22 | 1 | Lip seal kit |
| 22a ♦○ | 1 | Lip seal |
| 22b | 1 | Plate |
| 22c ♦○ | 1 | Seal ring |
| 23 | 1 | Plug |
| 23a | 1 | Plug, upper |
| 23b ♦○ | 1 | Seal ring |
| 24 | 3 | Clamp complete |
| 25 | 1 | Valve body |
| 26 ★ | 1 | Internal parts |
| 26a ♦★ | 2 | O-ring, NBR |
| 26b ★ | 2 | Spring |
| 26c ♦★ | 2 | O-ring |
| 26d ★ | 2 | Spindle |
| 26e ♦★ | 2 | O-ring, HNBR |
| 26f ★ | 2 | Plug |
| 26g ★ | 1 | Air fitting, swivel tee |
| 26h | 1 | Air fitting, swivel bend |
| 27 ♦○ | 2 | Seal ring |
| 28 | 1 | Valve body |
| 29 ♦○ | 2 | O-ring |
| 30 | 1 | Stem, lower |
| 31 | 1 | Plug |
| 31a ♦○ | 1 | Seal ring |
| 31b | 1 | Plug, lower |
| 32 | 1 | Valve body |

7 Parts list and service kits

The items refer to the parts lists in the following sections.

Service kits

| Denomination | DN 40 38 mm | DN 50 51 mm | DN65 63.5 mm | DN 80 76 mm | DN 100 101.6 mm |
|--|----------------|----------------|-----------------|----------------|--------------------|
| Service Kit for Actuator, detecting / CIP-valve ø32 | | | | | |
| □ Service kit | 9611920149 | 9611920149 | 9611920150 | 9611920151 | 9611920151 |
| Service Kit for Product wetted parts - detecting / CIP-valve ø32 | | | | | |
| ♦ Service kit EPDM | 9611920284 | 9611920284 | 9611920285 | 9611920286 | 9611920287 |
| ♦ Service kit NBR | 9611920288 | 9611920288 | 9611920289 | 9611920290 | 9611920291 |
| ♦ Service kit FPM | 9611920292 | 9611920292 | 9611920293 | 9611920294 | 9611920295 |
| Service Kit for Product wetted parts - valve with ø27 detecting/CIP-valve | | | | | |
| ○ Service kit EPDM | 9611920152 | 9611920152 | 9611920153 | 9611920154 | 9611920155 |
| ○ Service kit NBR | 9611920156 | 9611920156 | 9611920157 | 9611920158 | 9611920159 |
| ○ Service kit FPM | 9611920160 | 9611920160 | 9611920161 | 9611920162 | 9611920163 |

Parts marked with □♦○★△ are included in the service kits.


Recommended Spare Parts: Service kits.

900-104/2

7 Parts list and service kits

The items refer to the parts lists in the following sections.

7.4 SMP-BC stop valve - size DN125/DN150



CIP/detecting valve.
Diam. ø32.

7 Parts list and service kits

The items refer to the parts lists in the following sections.

Parts list

| Pos. | Qty | Denomination |
|--------|-----|--------------------------|
| 1 | 1 | Actuator, complete |
| 2 □ | 1 | Cap |
| 3 □ | 1 | O-ring |
| 4 | 1 | Guide ring |
| 5 | 1 | Plug |
| 6 | 1 | Cylinder |
| 7 □ | 1 | Spring packet |
| 8 □ | 1 | Lock wire |
| 9 □ | 1 | Guide ring |
| 10 | 1 | O-ring |
| 11 | 1 | Top pin |
| 13 □ | 1 | Piston |
| 14 □ | 1 | O-ring |
| 15 | 1 | O-ring |
| 16 | 1 | Air fitting |
| 18 □ | 1 | Bonnet |
| 19 □ | 1 | Guide ring |
| 20 ♦ | 1 | Guide ring |
| 21 ♦ | 1 | Lip seal |
| 23 | 1 | Valve body seal ring |
| 23a | 1 | Plug |
| 23b ♦ | 1 | Plug |
| 23c ♦ | 1 | Seal ring |
| 24 | 1 | Seal ring |
| 25 | 1 | Clamp complete |
| 26 | 1 | Valve body |
| 26a ♦○ | 2 | Internal parts |
| 26b ○ | 2 | O-ring, NBR |
| 26c ♦○ | 2 | Spring |
| 26d ○ | 2 | O-ring |
| 26e ♦○ | 2 | O-ring, HNBR |
| 26f ○ | 2 | Spindle |
| 26h | 1 | O-ring, FPM |
| | | Plug |
| | | Air fitting, swivel bend |

Service kits

| Denomination | NC |
|---|------------|
| Service Kit for Actuator | |
| □ Service kit | 9611920296 |
| Service kit for valve with ø32 detecting / CIP-valve | |
| ♦ Service kit EPDM | 9611920297 |
| ♦ Service kit NBR | 9611920298 |
| ♦ Service kit FPM | 9611920299 |

Parts marked with □♦○★△ are included in the service kit.


Recommended spare parts: Service kits.

7 Parts list and service kits


The items refer to the parts lists in the following sections.

7.5 Tools for plug seals

Tool for shut-off valve and change-over valve (upper plug)



Small seal ring




Large seal ring

* = Only for 38-51 mm/DN40-50 upper change-over plug (marking C8)

** = Only for DN125/150

Tool for change-over valve (lower plug).



Lower valve plug

7 Parts list and service kits

The items refer to the parts lists in the following sections.

Parts list

| Pos. | Qty | Denomination |
|------|-----|---------------------------------|
| 1 | 1 | Outer guide ring for large seal |
| 2 | 1 | Pin for tool |
| 3 | 1 | Inner guide ring for large seal |
| 4 | 1 | Tool housing, upper plug |
| 5 | 1 | Outer guide ring for small seal |
| 6 | 1 | Inner guide ring for small seal |
| 7 | 1 | Support part, upper plug |
| 8 | 1 | Outer guide ring, lower plug |
| 9 | 1 | Inner guide ring, lower plug |
| 10 | 1 | Support part, lower plug |
| 11 | 1 | Tool housing, lower plug |
| 12 | 1 | Tool housing, ch/o upper plug |
| 13 | 1 | Spacer (DN125/150) |

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.